

Specifications for applying  
**SPORTMASTER PROCUSHION SYSTEM**  
over Asphalt Court Surfaces

**CMT-26**

REVISED 02/22

**PRODUCT NAME**

SportMaster ProCushion System over asphalt court surfaces.

**DISTRIBUTION LOCATIONS**

SportMaster products are distributed through a world-wide network of stores and distributors. Call (800)395-7325 or visit [www.sportmaster.net](http://www.sportmaster.net) to find a location near you.

**1. SCOPE:**

**1.1**

The following specifications pertain to the application of the SportMaster ProCushion System over asphalt court surfaces. Refer to Product Technical Data sheets for specific mixing and application instructions.

**1.2**

SportMaster color coating systems are designed for use on properly built sport surfaces. Refer to the American Sports Builders Association for recommended guidelines on construction of court surfaces.

**2. SURFACE PREPARATION:**

**2.1**

New Asphalt surfaces must cure 14 to 30 days prior to application. The surface must be cleaned entirely of dust, dirt, debris, and all loose materials.

**2.2**

Fill all cracks with SportMaster Crack Magic, Acrylic Crack Patch, Acrylic Patch Binder or other suitable crack filler.

**2.3**

Level depressions or "bird baths" (1/8 inch or deeper) with SportMaster Acrylic Patch Binder or Acrylic Resurfacer patching mix.

**2.4**

Apply one or two coats of SportMaster Acrylic Resurfacer, as required by surface roughness and porosity, to provide a smooth underlayment for application of the SportMaster ProCushion System. A minimum of 2 coats are recommended on new asphalt surfaces.

**3. APPLICATION OF PROCUSHION SYSTEM LAYERS:**

**3.1**

Over properly prepared surface, apply (3) coats of CushionMaster II followed by (2) coats of CushionMaster I for the standard ProCushion system. For the premium ProCushion system, apply (5) coats of CushionMaster II followed by (2) coats of CushionMaster I.

**4. APPLICATION OF SPORTMASTER COLOR SYSTEM:**

**4.1**

Over properly prepared cushion layers, apply a minimum of two coats of the SportMaster Color Coating System in accordance with manufacturer's mixing and application instructions.

**5. LINE MARKINGS:**

**5.1**

Line markings shall be laid out according to the relevant sport organization instructions.

**5.2**

After masking tape has been laid, apply SportMaster Stripe Rite line primer to seal voids between masking tape and court surface to prevent "bleed under" when SportMaster Line Paint is applied.

**5.3**

Apply a minimum of one coat of SportMaster Line Paint.

**5. GENERAL:**

**5.1**

All work shall be performed in a workman like manner. All containers and debris shall be removed from job when completed.

Copyright© 2020, SportMaster  
All rights reserved.

ThorWorks Industries, Inc.  
P.O. Box 2277  
Sandusky, OH 44870

Phone: 1-800-326-1994  
FAX: 1-419-626-5477  
[www.sportmaster.net](http://www.sportmaster.net)