



Specifications for applying the
TrackMaster Rubberized Surface Coating
over asphalt running track surfaces

CMT - 27

Revised: 7/04

PRODUCT NAME:

TrackMaster Rubberized
Surface Coating Over
Asphalt Running Track
Surfaces

MANUFACTURER:

ThorWorks Industries, Inc.
2520 S. Campbell St.
Sandusky, OH 44870
Phone: 800-326-1994
Fax: 419-626-5477
www.thorworks.com

Additional Plant Locations:
SealMaster has a nationwide
network of manufacturing and
distribution facilities.

Phone 1-800-395-7325 or visit
www.sealmaster.net to find the
location near you.

1. SCOPE:

1.1

The following specifications pertain
to the application of the
TrackMaster Rubberized Surface
Coating over asphalt running track
surfaces. Refer to Product Data
Sheets for specific mixing and
application instructions.

2. SURFACE PREPARATION:

2.1

New asphalt surfaces must cure 30
days prior to application. The
surface must be cleaned entirely
of dust, dirt, debris, and all loose
materials.

2.2

Existing oxidized surfaces should be
primed with SportMaster Asphalt
Binder diluted 6 parts water to one
part Asphalt Binder.

2.3

Fill all cracks with Lane One patch
material or TrackFlex pourable
crack sealant.

2.4

Fill depressions and damaged areas
with Lane One patch material.

**3. APPLICATION OF
TRACKMASTER RUBBERIZED
COATING:**

3.1

Over properly prepared track
surface apply a minimum of
two coats of TrackMaster in
accordance with manufacturer's
mixing and application instructions.

4. LINE MARKINGS:

4.1

Line markings shall be laid out and
applied by qualified technicians in
accordance with the chosen
governing rules.

5. GENERAL:

5.1

All work shall be performed in a
workmanlike manner. All containers
and debris shall be removed from
job when completed.